


Installation of deep trunking

1. New Installation



Floor boxes will fit within the trunking at any point in the trunking run

2. Install into existing screed

